


NOTES:

- 1- RELAYS AND AIR SOLENOID VALVE ARE LOCATED IN LOWER FRONT CIRCUIT BREAKER PANEL AREA.
- 2- MICRO SWITCHES ARE PART OF THE FOLD DOWN LIGHT ASSEMBLY.



LET.	WAS	REVISIONS	DR.	APP.	CK.	CCN.	DATE	REL.

RELEASED CCN. 7959 **Blue Bird Wanderlodge** SCALE  $\infty$   
 FORT VALLEY, GEORGIA, U.S.A.

DIAGRAM: WIRING & DRIVING LIGHTS  
 DROP DOWN  
 DR 3-29-87 BY L. MANGANO  
 APP. 3-30-87 BY KENDALL  
 CK. 4-1-87 BY *BW*  
 SIZE B 1987 WLPT  
 3870490

TOLERANCE ON ALL DIMENSIONS IS, PLUS  OR MINUS  UNLESS OTHERWISE SPECIFIED.  
 INACTIVATES NOS.   
 REPLACED BY NOS.

FINISH COLOR OR TYPE MATERIAL:  
 RAW  PAINT   
 PRIME  PLATING   
 OTHER

FLAT SIZE: