



# Table of Contents

## Section I — Introduction

Contents	1-1
Checklists	1-1
Citizen's Band Transceiver	1-3
Hot Weather Operation	1-3
Cold Weather Operation	1-3
Campground Courtesy	1-4
Insurance	1-4
Safety Considerations	1-4
Vehicle Loading	1-6
Economical Driving	1-7
Engine Operating Hints	1-7
Fuel and Additives	1-7
Lubrication and Maintenance	1-7
Traveling in Your Motorhome	1-7
General Storage Notes	1-8
Emergency Assistance	1-8

## Section II — Operation

Instrumentation	2-1
Upper Dash Panel	2-2
Lower Dash Panel	2-4
Air Suspension System	2-5
Shifter Panel	2-7
Remote Control Heated	
Electrical Mirrors	2-8
Upper Right Hand Dash Panel	2-8
Lower Right Hand Dash Panel	2-8
Closed Circuit TV	
Monitor Panel	2-8
Monitor Control Panel	2-9
Overhead Control Center	2-9
UHF/VHF Television Receiver	2-9
Pilot's Area Overhead Dash	2-9
Co-Pilot's Area Overhead Dash	2-10
Steering Column Area	2-11
Floor Controls	2-12
Radar Detector	2-12
Seat Controls	2-13
CCTV and Line Up Operation	2-13
TV Antenna and Rotator System	2-13
CB Transceiver Unit	2-14
Diesel Engine/Transmission Operation	2-14
To Start Engine	2-14
To Stop Engine	2-14
Using the ZF Transmission Retarder	2-14
Trailer Hitch	2-15
Towing	2-15
Transmission Operation	2-15
Driving Tips	2-15
Accelerator Control	2-15

Transmission Oil Temperature	2-15
General Information	
Caterpillar 3208 Engines	2-16
Racor Fuel Filter	2-16
Fuel Line Heater	2-16
Leveling Jacks Controls	2-16

## Section III — Living Area Facilities

Sofa	3-1
Dinette Area	3-1
Galley Facilities	3-1
Refrigerator	3-1
Gas Cooktop	3-2
Microwave/Convection Oven	3-2
CORIAN Counter Tops	3-2
Food Center	3-3
Bathroom	3-3
Vent and Exhaust Fans	3-4
Heating Systems	3-4
Air Conditioners	3-5
Systems Monitoring and Control Panel	3-6
LP Gas Leakage Detector	3-7
Electronic Door Chime	3-8
Burglar Alarm/Anti-Theft Features	3-8
Fire Extinguisher	3-8
Smoke Detector	3-8
Bedroom Overhead Panel	3-9

## Section IV — Electrical Systems

12-Volt DC Supply System	4-1
Battery Heaters	4-1
Battery Chargers	4-1
DC Supply Monitors	4-2
AC Supply System	4-2
Power Line Monitors	4-2
AC Circuit Breaker Panels	4-2
Generator Operation	4-2
Shoreline Operation (Commercial Power)	4-3
Troubleshooting	4-3
Safeline Alarm	4-4
Audio System Wiring	4-4
Electronic Master Switch	4-4
Battery Storage in Freezing	
Weather	4-4

## Section V — Water Distribution and Drainage Systems

Water Supply and Distribution	
System	5-1
Commercial Water Hookup	5-1
Filling and Sanitizing	5-1
Potable Water Distribution System	5-2
Water Pump	5-2
Water Purifier	5-2



Water System Air Accumulator	5-3
Water Heater	5-3
Outside Faucet	5-3
Drainage System	5-3
Draining the Holding Tanks	5-4
Tank Level Detectors	5-4
Winterizing	5-4
Draining and Winterizing the Fresh Water Supply System	5-4
Draining the Ice-Maker	5-5

### Section VI — LPG System

LPG Tank and Controls	6-1
NEWTEC LPG Leak Detector	6-1
Fuel Requirements	6-2
Filling the LP Gas Tank	6-2
LP Gas and Vapor Detectors	6-2
Regulator Pressure	6-2
Operation	6-2
Checking for Leaks	6-3
LPG Consumption	6-3
LPG System Warnings	6-3

### Section VII — Air Brake Systems

Operation	7-1
Brake Failures	7-1
Additional Air Operated Equipment	7-1
Compressed Air System Air Dryer	7-2

### Section VIII — Owner Maintenance Data

Specifications and Data	8-1
Changing Wheels/Tires	8-3
Checking Torque on Dual Wheels	8-5
Battery Maintenance	8-5
Periodic Battery Checks and Maintenance	8-5
Exterior Care	8-5
Interior Care	8-5
Fluid Level Checks	8-6
Crankcase Oil Level	8-6
Power Steering Reservoir Fluid Level	8-6
Transmission Fluid Level	8-6
Importance of Proper Oil Level	8-6
Oil Check Procedure	8-6
Racor Fuel Filter and Water Separator System	8-6
Filter/Separator Operation	8-6
In-Filter Fuel Heater	8-7
Water-In-Filter Alarm	8-7
Maintenance	8-7

Fuel Tank Sending Unit Location	8-7
Leveling Jacks Reservoir	8-7
Engine Cooling System Refill	8-7
Cooling System Additives	8-8
Windshield Washers	8-8
Jump Starting	8-9
Generator	8-9
Maintenance Schedules	8-9
Generator Troubleshooting	8-10
Generator Overloads	8-10
Storage Procedures	8-11
Refrigerator	8-11
Water Pump	8-11
Holding Tank Drain	8-11
Clock/Thermometer Calibration Procedures	8-12
Thermometer Calibration Procedures	8-12
Tub/Shower Mixing Valve	8-12

### Section IX — General Information Equipment Manufacturers

### Section X — Diagrams

### Section XI — Equipment Options

Awnings	11-1
Open Awning	11-1
Close Awning	11-1
Fabric Care	11-2
Washing	11-2
Water Leaks	11-2
Storm Precautions	11-2
Hardware and Mechanism Maintenance	11-2
At the End of Each Season	11-3
Ice-Maker	11-3
Ice-Maker Operation	11-3
Ice-Maker Maintenance	11-3
Winterizing	11-3
Kool-O-Matic Ventilation Fan Operation	11-3
Auxiliary Air Compressor Operation	11-4
Maintenance	11-4
Driving Lights	11-4
Skylight	11-4
Inverter	11-5
Microphor Toilet	11-5
Power Dump Valves	11-5
Quick Start Aid	11-5
Intercom System	11-5
Heated Holding Tanks	11-5



# List of Illustrations

<b>Fig. No.</b>	<b>Title</b>	
1-1	Federal Certification Label	1-6
1-2	Identification Plates	1-6
2-1	Pilot/Co-Pilot Compartment	2-1
2-2	Dash	2-2
2-3	Upper Dash Panel	2-3
2-4	Lower Dash Panel	2-5
2-5	Shifter Panel	2-7
2-6	Upper Right Hand Dash Panel	2-8
2-7	Lower Right Hand Dash Panel	2-8
2-8	Closed Circuit TV Monitor Panel	2-8
2-9	Monitor Control Panel	2-9
2-10	Overhead Control Center	2-9
2-11	Pilot's Area Overhead Dash	2-9
2-12	Co-pilot's Overhead Dash	2-11
2-13	Steering Column Area	2-12
2-14	Seat Controls	2-13
2-15	CCTV Camera Port	2-13
2-16	Extendable TV Antenna Radome	2-13
2-17	Antenna Control Panel	2-14
2-18	C.B. Transceiver Unit	2-14
2-19	Leveling Jack Controls	2-16
3-1	Dinette Area	3-1
3-2	Galley Facilities	3-1
3-3	Refrigerator Operating Controls	3-1
3-4	Gas Cooktop	3-2
3-5	Food Center	3-3
3-6	Toilet	3-3
3-7	Vent/Exhaust Fan	3-4
3-8	Heater Thermostat	3-4
3-9	Roof Air Conditioners	3-6
3-10	Systems Monitoring and Control Panel	3-6
3-11	LP Gas Leakage Detector	3-8
3-12	Electronic Door Chime	3-8
3-13	Bedroom Overhead Panel	3-9
4-1	Typical Load Center	4-1
4-2	Battery Compartment	4-1
4-3	AC Power Selector Switch	4-2
4-4	Shoreline/Utility Compartment	4-3
5-1	Location of Commercial Water Hookup	5-1
5-2	Air Accumulator Water Pump and Water Tank Drain Valve	5-2
5-3	Water Purifier Location	5-3
5-4	Accumulator	5-3
5-5	Location of Holding Tanks Drain Valve	5-4
6-1	LPG Tank Compartment	6-1
8-1	Locating Jack	8-4
8-2	Lug Nut Tightening Pattern	8-4
8-3	Racor Fuel Filter/Separator	8-6
8-4	Tub/Shower Mixing Valve	8-12
10-1	Diagram, Chassis and Water Heater Circuits	
10-2	12 Volt Diagram, Component Identification Lower Front Load Center	
10-3	12 Volt Diagram, Overhead Front Load Center	
10-4	12 Volt Diagram, Left Front Load Center	
10-5	12 Volt Diagram, Right Front Load Center	
10-6	12 Volt Diagram, Rear Load Center	
10-7	12 Volt Diagram, Batteries and Charging Circuits	
10-8	Potable Water System	
10-9	Drainage System	
10-10	Liquid Petroleum Gas System	
10-11	Air System (Sheet 1)	
10-11	Air System (Sheet 2)	
10-12	Chassis Lubrication Guide	
11-1	Awning Opening Procedure	11-1
11-2	Awning Opening Procedure	11-1
11-3	Awning Opening Procedure	11-1
11-4	Awning Opening Procedure	11-1
11-5	Ice-Maker Details	11-3
11-6	Skylight	11-4
11-7	Glass Adjustment Detail	11-4
11-8	Intercom System	11-5



## List of Tables

<b>Table No.</b>	<b>Title</b>	
4-1	Electrical Ratings for Motorhome Appliances .....	4-3
8-1	Engine and Chassis Specifications ..	8-1
8-2	Engine/Chassis Capacities .....	8-1
8-3	Generator Capacities and Specifications .....	8-2
8-4	Motorhome Capacities and Specifications .....	8-2
8-5	Maintenance Schedule Summary ...	8-2
8-6	12-Volt Light Equipment, and Fuses, Current Usage .....	8-3
8-7	Generator Maintenance Schedule ...	8-9
8-8	Anti-Freeze Protection Chart .....	8-10
8-9	Water Pump Troubleshooting Guide .	8-11